

RGB用コントローラ 機能表 1~36

●ディップスイッチの切り替えにより、下記一覧のように点灯パターンや点灯スピードを変えることができます。

◆点灯パターン

	DIP SWITCH											【色説明】 R (赤) / O (オレンジ) / Y (黄色) / Y.G (黄緑) / G (緑) B.G (水色) / B (青) / V (紫) / P (ピンク) / W (ホワイト) RAINBOW (R→O→Y→G→B→W→V)	
	1	2	3	4	5	6	7	8	9	10			
1	Off	Off	Off	Off	Off	Off		Off			<div style="border: 1px solid black; padding: 2px; display: inline-block;">点滅 ①</div> (P8 On→常灯)	点灯→消灯を繰り返します。	R
2	On	Off	Off	Off	Off	Off		Off					O
3	Off	On	Off	Off	Off	Off		Off					Y
4	On	On	Off	Off	Off	Off		Off					Y.G
5	Off	Off	On	Off	Off	Off		Off					G
6	On	Off	On	Off	Off	Off		Off					B.G
7	Off	On	On	Off	Off	Off		Off					B
8	On	On	On	Off	Off	Off		Off					V
9	Off	Off	Off	On	Off	Off		Off					P
10	On	Off	Off	On	Off	Off		Off					W
11	Off	On	Off	On	Off	Off		Off			<div style="border: 1px solid black; padding: 2px; display: inline-block;">点滅 ②</div> (P8 ON→Reverse)	点滅しながら発光色が変わります。	RGB
12	On	On	Off	On	Off	Off		Off					RGBW
13	Off	Off	On	On	Off	Off		Off					RAINBOW
14	On	Off	On	On	Off	Off		Off			<div style="border: 1px solid black; padding: 2px; display: inline-block;">色切換</div> (P8 ON→Reverse)	発光色の切換を繰り返します。	R-W
15	Off	On	On	On	Off	Off		Off					O-W
16	On	On	On	On	Off	Off		Off					Y-W
17	Off	Off	Off	Off	On	Off		Off					Y.G-W
18	On	Off	Off	Off	On	Off		Off					G-W
19	Off	On	Off	Off	On	Off		Off					B-W
20	On	On	Off	Off	On	Off		Off					V-W
21	Off	Off	On	Off	On	Off		Off					P-W
22	On	Off	On	Off	On	Off		Off					RGB
23	Off	On	On	Off	On	Off		Off					RGBW
24	On	On	On	Off	On	Off		Off			<div style="border: 1px solid black; padding: 2px; display: inline-block;">BIT WAVE ①</div> (P8 ON→Reverse)	暗→明→消灯を繰り返します。	RAINBOW
25	Off	Off	Off	On	On	Off		Off					R
26	On	Off	Off	On	On	Off		Off					O
27	Off	On	Off	On	On	Off		Off					Y
28	On	On	Off	On	On	Off		Off					Y.G
29	Off	Off	On	On	On	Off		Off					G
30	On	Off	On	On	On	Off		Off					B.G
31	Off	On	On	On	On	Off		Off					B
32	On	On	On	On	On	Off		Off					V
33	Off	Off	Off	Off	Off	On		Off					P
34	On	Off	Off	Off	Off	On		Off			<div style="border: 1px solid black; padding: 2px; display: inline-block;">BIT WAVE ②</div>	暗→明→消灯を繰り返しながら発光色が変わります。	W
35	Off	On	Off	Off	Off	On		Off					RGB
36	On	On	Off	Off	Off	On		Off					RAINBOW

RGB用コントローラ 機能表 37~64

◆点灯パターン

	DIP SWITCH												
	1	2	3	4	5	6	7	8	9	10			
37	Off	Off	On	Off	Off	On		Off			<div style="border: 1px solid black; padding: 2px;">FADE①</div> (P8 On/Off→無効)	暗→明→暗→明を繰り返します。	R
38	On	Off	On	Off	Off	On		Off					O
39	Off	On	On	Off	Off	On		Off					Y
40	On	On	On	Off	Off	On		Off					Y.G
41	Off	Off	Off	On	Off	On		Off					G
42	On	Off	Off	On	Off	On		Off					B.G
43	Off	On	Off	On	Off	On		Off					B
44	On	On	Off	On	Off	On		Off					V
45	Off	Off	On	On	Off	On		Off					P
46	On	Off	On	On	Off	On		Off					W
47	Off	On	On	On	Off	On		Off			<div style="border: 1px solid black; padding: 2px;">FADE②</div> (P8 ON→Reverse)	暗→明→暗→明を繰り返しながら色が変わります。	RGB
48	On	On	On	On	Off	On		Off					RGBW
49	Off	Off	Off	Off	On	On		Off					RAINBOW
50	On	Off	Off	Off	On	On		Off			<div style="border: 1px solid black; padding: 2px;">Still Camelean①</div> (P8 ON→Reverse)	発光色がゆっくりと変わりそれを繰り返します。	R-W
51	Off	On	Off	Off	On	On		Off					O-W
52	On	On	Off	Off	On	On		Off					Y-W
53	Off	Off	On	Off	On	On		Off					YG-W
54	On	Off	On	Off	On	On		Off					G-W
55	Off	On	On	Off	On	On		Off					BG-W
56	On	On	On	Off	On	On		Off					B-W
57	Off	Off	Off	On	On	On		Off					V-W
58	On	Off	Off	On	On	On		Off					P-W
59	Off	On	Off	On	On	On		Off					R→G→B
60	On	On	Off	On	On	On		Off			R→G→B→W		
61	Off	Off	On	On	On	On		Off			Rainbow		
62	On	Off	On	On	On	On		Off			<div style="border: 1px solid black; padding: 2px;">Still Camelean②</div> (P8 ON→Reverse)	上記よりゆっくりと色が変わります。	R→G→B
63	Off	On	On	On	On	On		Off					R→G→B→W
64	On	On	On	On	On	On		Off					Rainbow

◆点灯スピード一覧表

@									Off	Off	(Speed)	早
@									On	Off		↑
@									Off	On		↓
@									On	On		遅